

# PADDOCK CLEANER100/500 PARTS DIAGRAM

10/07



1A -FRAME 100 HAND & TOW	PAD 1006	13 - THROTTLE BRACKET	PAD1015
1B -FRAME 200 TOW TIPPING	PAD1007	14A -WHEEL 500	PAD400-8REDK358
2 - PLASTIC HOPPER	PAD1005	14B -WHEEL 500+	PAD16X6.50-4PRST50T
3 - HOSE 2.5M	PAD1034	15A - WASHER	PAD1027
4 - PICKUP NOZZLE	PAD1072	15B-SPLIT PIN	PAD1028
5 - CHAIN	PAD1050	17 - ENGINE FRAME	PAD1008LONG
6A -DOOR RETAINER FEMALE	PAD1067	18 -FILTER	PAD1017
6 B- DOOR RETAINER MALE	PAD1066	19 -FILTER BRACKET	PAD1018
7 - HOSE	PAD1029A	20 -LITTER FILTER	PAD1049
8A - SPIGOT FOR HOSE	PAD1039	21 -FILTER SOCK	PAD1049 SOCK
8B - SPONGE GASKET	PAD1043	22 - PLATE	PAD1026
9A -TOW BAR 3" RISE	PAD1012	23 -ENGINE UNIT	KRB400-B BLOWER
9B -TOW BAR 11" RISE	PAD1013	24 - AIR REDUCER GAUZE	PAD1016
9C -ANTI ROLE TOW BAR 3"	PAD1060	25 -SEAL	PAD1088
10 - SCRAPER PLATE BLOWE	PAD1073	26 - HOSE CLIP 125mm X2	F10182
11 - 50mm BALL HITCH	PAD1004	27A - CATCH FEMALE	PAD1070
12A-DROP PIN HITCH FOR 9A	PAD1014	2B - CATCH MALE HOOK	PAD1071
12B- DROP PIN HITCH FOR 9C	PAD1014S	---- FOOT PEDAL SPRING	PAD1075
		----ANTI STATIC WIRE	PAD1056